## **Product Information**

# Video Cloud Gateway AVC1



Index	Page
Product description - Intended use - Scope of functions	2
Safety instructions Technical data	3 3
Device overview - Display of control elements	4 4
Assembly and installation - Assembly on DIN rail - Connection	5 6
Operation - HW Settings - Network settings	7 8
Service	12

### **Product description**

#### Intended use

The AVC1 device is a cloud gateway with an integrated video server. It converts TC:Bus signals to network protocol (IP) level and connects the **KochCloud** to the TC:Bus. The device is designed to be mounted on a DIN rail in the control cabinet. To carry out any programming, the user must have an external device (e.g. laptop) and an account on <u>https://kochcloud.ch</u>.



The manufacturer assumes no liability for use that deviates from or goes beyond the stipulated intended use.

#### Scope of functions

- Image resolution VGA (640 x 480)
- Supports JPEG, Motion-JPEG, H.264 for video streaming, 25 fps
- TC:Bus connection via 6-wire technology using screw connectors, P-supply with 15-28 VDC
- RJ45 port for Ethernet connection
- Built-in differential 2-wire video receiver
- Visual status and error display via LED
- Web interface in four languages (German, French, Italian and English)
- Half-duplex audio connection
- IP address configuration can be done with STC-C configuration software
- Cloud gateway control during voice transmission via commands
- Jumper can be set as terminating resistor for video signal path
- Secure external connection via TLS
- Corresponds to DIN 50486

### Safety instructions

U

- The safety regulations for high-voltage installations must be observed when working on systems with a 230 V AC mains connection.
- Only qualified electricians may carry out the assembly, installation and start-up work.

The general safety regulations for telecommunications systems apply to the installation of TC:Bus systems.

- Separate routing of high-voltage and low-voltage lines
- A minimum distance of 10 cm between joint cable routing
- Add Spacers between high-voltage and low-voltage lines in shared cable ducts
- Recommended cable: G51 4x2x0.8 (twisted pair)
- Lines with different diameters already in place (renovations) can be used if the loop resistance (< 20  $\Omega$ ) is taken into account.

Suitable steps must be taken to protect against lightning to ensure that the voltage on the TC:Bus wires a and b does not exceed 32 VDC.

### **Technical data**

Operating voltage: Input voltage when idle: Maximum input current:	15-28 VDC I(a) = 0,1 mA, I(P) = 200 mA I(Pmax) = 250 mA
Video stream	Image format JPEG, Motion-JPEG, H.264 Resolution VGA (320 x 240), VGA (640 x 480)
Housing:	Plastic, serial installation housing 6 TE (DIN 43880) for DIN rail (DIN EN 60715)
Dimensions (WxHxD)	105 x 90 x 75 mm
Protection class Permitted ambient temperature	IP20 0°C + 40°C

#### Note: Only tc:bus 6-wire technology can be used!

### **Device overview**

- **1** Terminals a, b, P, M,
- 2 Video-IN and -OUT Terminals
- 3 Terminating resistor (jumper)
- 4 LED, green (ready for use indicator light)
- 5 LED, yellow (network and SD card error indicator light)
- 6 LED, red (TC:Bus error indicator light)
- 7 Reset button (device restart)
- 8 WE button (restore factory settings)
- **9** RJ45 port with LED status (network connection)



4	Green LED: Ready for use indicators	<ul> <li>ON: ready for use</li> <li>Flashing: loading factory settings</li> </ul>
5	Yellow LED: Network/SD error indicator light	<ul> <li>Flashing slowly: Network error</li> <li>ON: Device powering up</li> </ul>
6	Red LED: TC:Bus error indicator light	<ul> <li>ON: Firmware update is being installed</li> <li>Flashing: TC:Bus error</li> </ul>

### Assembly and installation

#### Caution!

The AVC1 may only be assembled and dismantled when the device is disconnected from the power supply!

T1 and T2 must <u>not</u> be connected with another wire. The polarity should be noted when connecting video wires T1 (-) and T2 (+). If the image is unclear after the device has been started up, switch it off and swap the wires for the video signal.

#### Mounting on the DIN rail

• Place the AVC1 on the DIN rail





#### Removing the AVC1 from the DIN rail

- Press the locking mechanism down using a screwdriver
- Pull the AVC1 away from the DIN rail from underneath and lift it off



#### Connection

Screw connectors:

- A size 0 screwdriver is suitable for operating the screw terminals and buttons on the AVC1.
- · Connect additional wires with auxiliary terminals
- Only use cables of the same material and diameter for each terminal contact
- Observe the installation diagram provided with the system

Network connection: RJ45 patch cable (CAT.5 FTP 8-pin)

 Connect the TC:Bus wires (a, b, P, M, T2, T1) as per the installation diagram provided



• Connect the RJ45 interface of the AVC1 and network with a patch cable



### Operation



Only connect the power supply after completing all the installation steps!

- Check wires a, b and P for short-circuiting
- T1 and T2 must not be connected with another wire.
- The polarity should be noted when connecting video wires T1 and T2. If the image is unclear after the device has been started up, switch it off and swap the wires for the video signal

#### **HW Setting**



#### **Network settings**

Installing an IP network is a very intricate procedure due to the numerous interdependent parameters and settings. The procedure requires a lot of background knowledge. Please contact your network administrator for this.

#### IP addresses and DHCP server

Every device used in a network requires an **IP address**. Devices that communicate with each other must also be on the same **subnet**.

Home networks are usually set up as follows:

#### **Network number**

The same for every device in the



Why have a fixed or dynamic IP address?

Devices that provide a service should have a fixed IP address.

Devices that only request services can be assigned a dynamic IP address by the DHCP server.

Example: An external video intercom station provides various receivers with a service (video image) and should therefore have a fixed IP address.

The receivers, e.g. smartphones, request the service (video image), but

do not actually provide the service. That is why the DHCP server can assign them a dynamic IP address.

#### Network settings with STC-C software

The following network parameters can be set in the STC-C software:

- (De)activate DHCP IP address
- Subnet mask
- DNS server
- Gateway
- Management of Admin and User passwords

(De)activate DHCP			
<ul> <li>Start STC-C on PC</li> <li>Check or uncheck the DHCP checkbox</li> </ul>	DHCP aktivieren		
• Update the EEPROM from the AVC1.	IP Adresse	192.168.1.200	
For more information about STC-C refer to the program's help section.	Subnetzmaske	255.255.255.0	
	Gateway	192.168.1.1	
	DNS Server	192.168.1.1	
		Passwort "User"	
Password = AVC1 serial number			
		Passwort "Admin"	
		Webinterface	


Notes

#### 10/12

### Service

You can find answers in our list of frequently asked questions <u>www.kochag.ch</u> **FAQ** (German and French only) >>>

For direct support, please contact our technical customer service team:

Phone 044 782 6000



René Koch AG Seestrasse 241 8804 Au/Wädenswil 044 782 6000

info@kochag.ch www.kochag.ch



Subject to technical changes